


Spark Plug Readings

Example number 1



Lets analyze this plug, sorry the numbered points aren't clear but it's 1-4 you can figure it out.

Number 1 Is a timing indicator, you'll see a definite colour change on the ground strap it doesn't show well here but you can still see it right about at the arrow. Too much timing and the colour change will be very close to the threaded body of the plug, too little and it'll be closer to the tip. Ideally we want it right in the apex or centre of the 90 bend on the ground strap. This plug shows too much timing for the combustion chamber efficiency or octane level.

Number 2 The tip of the ground strap is loaded with OIL deposits, fuel deposits are usually flat black in colour and almost like a fine powdery deposit, this motor is leaking oil into the combustion chamber, bad valve guides, leaking valve covers allowing oil to seep through the plug threads, whatever it needs to be fixed.


Number 3 The threaded portion of the plug gives you the heat range, look at the threads you'll see that a few toward the tip are a dull burnt looking colour the rest are black and shiny. You want about 2 threads showing the heat on the end of the plug and the rest of the threads to be shiny, this plug is impossible to read because of the oil mess. If you using a longer reach plug than this one 2.5 to 3 threads is optimum. To increase the number of burnt threads increase the heat range of the plug, if you

have 4-5-6 threads burnt you need to get a colder plug

Number 4 shows another indicator of timing, you'll usually see a brown ring right at the tip of the porcelain area it should be a sharp and defined ring about .020 wide. Wider indicates not enough timing and any smaller, or only 1/2 way around or nonexistent as in this image is the second indication of too much timing in the motor.

Looking at the colour of the porcelain this carb has a passing grade at the mid range and not too bad on the idle circuits although the oil leaking into the chamber makes it tough to really get a good read.

Example Number 2



This plug is showing by the deposits on the tip of the electrode and also the deposits right on the edge of the threaded body that it's slightly rich at idle.

The white porcelain is showing a lean condition at WOT, it's not too far advanced as the total timing mark or colour change is right in the apex of the ground strap curve. The Idle timing is shown by the triangular hazing up on the flat of the ground strap and without even looking at the distributor specs the timing on this SB Mopar is about 18-20 initial and 34 total.

The heat range of the plug isn't clear as the picture isn't good enough

Changes:

You would need to try and lean it out just a touch at idle and up the jets by 2 points to

richen up the WOT circuit.

That slightly lighter colour at the tip of the ground strap indicates too much gap, nothing serious but next time you change plugs go to about a .036 gap from the current .040.

Too much resistance caused by too wide of a plug gap can cause excessive heat on the tip which will shorten the life of the plug and really give you no benefits. Excessive plug gaps are not required on most Muscle and bracket cars, once you get into real big compression and major power you would open up the gap and replace plugs 2-3-4 times a year.



Let's look at Image 1.....

Note the change of colour on the ground strap and its position, this shows a timing issue. Unfortunately the reader who sent this image in didn't say what engine he was working on but by the condition of the plug it's probably a Small Block Chevy, 3 years old with 38* total timing and an Edelbrock Carb..... 😊

In the second image a green arrow is used to show the area where we want the timing mark to be on this engine and of course you can see that the motor has too much timing.

Image 3 shows only one thread heated on the plug and rest are oil soaked and wet this normally indicates that the plug is too cold, the oil indicates a valve cover leak and a New set of Cometic Aramid fiber gaskets would cure it.



The colour on the plug indicates a decent idle A/F ratio and a good ignition system probably an MSD or some other type of aftermarket ignition. The hot spark is keeping the porcelain clean on the top area anyhow. Now if we look down into the bottom of the plug as seen in the above image where the porcelain reaches below the steel body we see black deposits indicating a rich condition at mid range to WOT. I would guess this engine is a little lazy in mid range and could get better mileage.

Changes:

Back off the total timing but keep whatever the initial is as it appears pretty good, I would shorten the total by 4* and do another check.

Fix the oil leak

Go up one heat range and after about 50 miles check to see if you have 2-3 threads heated up and discoloured for correct heat range. Heating up the plug will help reduce the carbon build up and further tuning with the A/F ratios can be done

Before you can really tell what to do with the carb the ignition must be right as well as the correct heat range on the plug to get true readings.

This is what you don't want...

a little too much timing and or not enough fuel. Note the spark plugs completely melted. The piston detonated itself into fragments and beat the combustion chamber to a pulp...

The hole in the piston in the second picture is not a window to inspect the wrist pin, although it seems to work well....



Where's the ground strap?

WOT Race Tuning

Ignition timing and A/F ratio's are critical to achieving optimum performance between going to far and falling off the edge into detonation or being so rich as to not reach maximum power potential.

The best way to tune for WOT is by doing a shut down at the end of the track and doing a proper WOT reading on the plugs, use caution, coast to a safe spot away from return lane traffic. Or tow the car back to the pits where you can read all 8 plugs for combustion chamber efficiency.

Accurate measurement of the combustion chamber temperature is the only way to achieve the perfect tune up. A combination of an O2 Sensor with a data logging feature combined with accurate and rapid responding EGT Gauges will achieve the quickest and most accurate track tuning. Dyno's are OK for a baseline setting, **NO** DYNO will ever replace a good track tuner with the right tools.

I look at it this way....you spend loads at the dyno shop but all conditions are determined by the dyno operator and climatic conditions of the ambient air of the particular day of the test. You now take your engine and bolt it into a car with a transmission, engine compartment heat, different fuel, fuel pressure variances, G forces, tire slip, wheel stands, elevation etc. All your money did was set a baseline which can easily be done in your own shop with a screwdriver.

Spend that money on a WEGO 5 wire, wide band, data logging O2 sensor, it'll last for years and give you accurate combustion chamber efficiency from the burn-out box to the freeway. Team that up with a Stewart Warner EGT (Exhaust Gas temp gauge) and it won't matter if it's 105* or 55* outside, 300' or 5,000' elevation you'll be able to make decisive changes with no guess work or risk to your investment.

If your interested in a WEGO or EGT system call I'd be happy to discuss how they work with you.

The Air/Fuel Map

Look at the porcelain and divide it into 3 areas, top, middle and bottom in about 1/3rds.

Top Area: This area is your idle circuit and for the racer really has very little meaning. However if your car is a street driven vehicle then we need to attempt to get this portion to a dark grey colour by tuning the AFR, Idle Air Bleeds and the four corner Idle adjustments until we get a clean crisp idle and total combustion of the fuel at idle. Keep in mind that the idle circuits are totally isolated from the rest of the carburettor and can be tuned with very minimal affect on the WOT position A/F Ratio.

Centre Area: This is the area that will show the combustion chamber condition at part throttle or cruise with the power valve and secondary venturi's closed. Usually about 30-50 MPH depending on the gear and weight of the car.

Bottom Area: This is where the racer needs to concentrate all his efforts, using a 5x or 10x scope you need to look right down to the bottom of the porcelain where it meets the metal housing of the plug. This is the area that will leave the colour that you need to study and tune to. The other 2/3rds of the porcelain will be burned clean by the high heat generated by WOT and high RPM, this is not the time to read for cruise or Idle characteristics.

We're looking for a coloured ring right at the base of that porcelain which I refer to as a Fuel Ring. The colour will vary depending on the type of fuel you're burning, Unleaded Pump gas will leave very little colour because of all the additives such as injector cleaners and methanol. A 108 or 110 octane fuel will leave a tan colour while the C17 and higher octane fuels will leave an almost grey fuel ring. If you study the ring you will see that it starts to show colour just below the base of the ground strap, this is caused by the shielding affect of the strap leaving that portion cooler thus showing the most colour. The ring will develop from each side and form a full circle of correct colour as

you get closer and closer to the correct tune up. If you look down into the bottom of the porcelain and you detect a thin oily deposit you are seeing oil from the combustion chamber caused by either worn or improperly seated rings, you may also detect this with a new engine that hasn't fully seated the rings yet, just don't confuse this with the "Fuel Ring".

Plug Characteristics

Shiny or Glazed Porcelain: This occurs for two reasons, excessive idling or rich idle condition leaving heavy soot deposits. These deposits will burn and create excessive porcelain temps causing the glass to melt usually resulting in a down track popping through the exhaust..

You will usually see splotchy deposits on the plugs after the run, either green or yellow in color and of course the tell tale shiny glaze. The porcelain should have a chalky or dull finish.

Base of threads sooty: This is usually an indication of the plug not being tight enough allowing air to be pulled in to the chamber and fuel being pushed out, change the plug, tighten to spec. This area should have a nice dark to medium grey colour without heavy deposits.

Black or brown specs: This is an indication of detonation usually caused by too hot of a plug, drop one or two heat ranges and it should go away. The plug gets so hot that it will start to detonate the fuel before the ignition fires, this causes a double flame front and reduces the efficiency of the combustion process as these two flame fronts battle each other in the combustion chamber. The black spots are the result of the fuel deposits being burned onto the porcelain by the double flame front. Once you cool down the plug and remove the secondary ignition source you can re-set your timing to produce the correct combustion chamber temp for optimum power.

Do not underestimate the damage that this condition can do to your engine, drop the plug heat range.

Shiny little diamond like deposits: It's too late you've already started to blow the pistons out of it. Start over from scratch, fatten the carb, back-up the timing and cool down the plugs. Now start a proper tuning procedure and hopefully you caught it before too much damage was done.

No colour mark on ground strap: If you're showing good colour on the porcelain but the ground strap fails to show an indicator then your plug is too cold, go up 1 heat range.

If the ground strap is showing a good colour line but the porcelain is showing no colour at the base then your plug is too hot, drop down a range.

Try using 3 different ranges on one bank, make a pass and from those three different plugs determine which one is correct for the engine.

Variable heat readings: On a small block motor most have adjoining exhaust ports, these will always be your hottest cylinders and in some cases where there has been excessive port work and thinning of the metal between the ports it may be necessary to run a plug one step cooler in those cylinders, use a plug indexing washer to back the timing down in those cylinders slightly, or if you have an adjustable ignition system you may want to electronically back the timing down in the hot cylinders.

[Spark Plug Reading](#) [Carb Sizing](#) [Hydraulic Cam Installation and Braking](#) [Mopar Rear Ends Remove/Install your Distributor](#)

[Cross Reference Demon to Holley](#) [Mopar Valve Geometry](#) [Torsion Bar Removal](#) [Mopar Ignition Wiring Diagrams](#)

[What size Fuel Pump do you Need](#) [Basics of Cam Specs](#) [Mopar Distributors](#) [Demon Carburetion Sales Policy](#)

[Valve Adjustment Chart](#) [Ignition Tune Up Help](#) [Mighty Demon Q&A](#) [Secrets of Cam Design](#) [Voltage Regulators](#)

[4 Pin/2 Pin Ballast Resistor](#) [A688 Drop Cylinder Test](#) [A688 Q&A](#) [Computer Controlled Ignition Swap GM HEI Distributors](#)

[Dual Pickup Conversion Instructions](#)

[Home Page](#)

[About Us](#)

[Pickups](#)

[Dodge Ram Parts and Accessories](#)

[Parts](#)

[FBO Systems](#)

[Mopar Tech](#)

[Dodge Ram Tech](#)

[Links](#)

[OBDII](#)

[TCS](#)
[Performance Parts](#)

[Kenlowe Products](#)

[Cometic](#)

[PI THON](#)

[Miscellaneous](#)

[Site Map](#)

[Terms & Conditions](#)

[Contact Us](#)